



ELEVATION




NOTES

- After beams have been erected, holes shall be drill into substructure and anchor dowels placed. Dowel holes shall be filled with non-shrink grout to top of beam and allowed to cure min. 24 hours prior to grouting the shear keys.
- 2. Longitudinal keys shall be grouted.
- 3. The 1" \$\phi\$ rods in the tranverse tie assembly shall be tightened to a snug fit and the threads set. Pockets that receive transverse tie bar outside shall be filled with grout after transverse tie assembly is in place.
- 4. The bearing seat surfaces shall be adjusted by shimming to assure firm and even bearing. Two ¹₈" fabric adjusting shims of the dimensions of the Exterior Bearing Pad shall be provided for each bearing.

SHEET NO. 2 5 SHEETS



CROSS SECTION
(Looking West)



STONE RIPRAP ANCHOR DETAIL

